

HEAT SEALER MAINTENANCE SCHEDULE	LIGHT DUTY				EXTREME DUTY			
	FREQUENCY IN HOURS				FREQUENCY IN HOURS			
	8	40	160	1040	8	40	80	520
OPERATION								
Check all fasteners, bolts, nuts, screws are tight				X				X
Check the seal height mechanism operates freely. A small amount of white lithium grease may be used to lubricate lift mechanism if needed.				X				X
Replace orange silicone rollers and bearings. Do not reuse old bearings				X				X
Remove white plastic timing belt tensioners and check bottom flange for wear. When roller wears out, the bottom surface will contact bottom plate of sealer. If the plating is worn beneath roller, replace roller and lubricate tensioner with greater frequency.				X				X